


# GB122

## DE, AT, CH



6720905947.aa.RS-GB122

# Buderus



### Wichtige Hinweise

- Ersatzteile dürfen nur von einem zugelassenen Installateur eingebaut werden!
- Im Anhang finden Sie:
  - die Übersetzungen aller verwendeten Teilebezeichnungen
  - eine Übersicht der Gerätetypen und Länder, für die diese Ersatzteilliste gilt.

### Important notes

- The spare parts may only be installed by an approved installer!
- In the appendix you will find:
  - a list of translations of the names of all parts used
  - a list of the models and countries to which this spare parts list applies.

### Indications importantes

- L'installation des pièces de rechange doit être effectuée par un professionnel qualifié!
- Veuillez trouver en annexe:
  - les traductions de toutes les désignations des pièces utilisées
  - une vue globale des types de chaudières et des pays pour lesquels la présente liste des pièces de rechange est valable.

### Informações importantes

- Peças de substituição só podem ser montadas por um técnico credenciado!
- Em anexo encontra:
  - as traduções das designações de todas as peças utilizadas.
  - lista dos aparelhos e países para os quais esta lista de peças de substituição é válida.

### Avvertenze importanti

- Le parti di ricambio possono essere montate esclusivamente da personale qualificato ed in possesso dei requisiti tecnico-professionali!
- In appendice sono reperibili:
  - traduzione di ogni descrizione relativa alle varie parti di ricambio
  - elenco di sigle e codici, corrispondente ai vari paesi di destinazione.

### Indicaciones importantes

- Los repuestos solamente deben ser montados por los servicios técnicos oficiales de la marca!
- En el anexo podrá encontrar:
  - la traducción de todas las denominaciones de piezas empleadas
  - una relación de los tipos de aparato y países en los que se aplica esta lista de repuestos.


### Belangrijke aanwijzing

- Onderdelen mogen alleen door een erkend installateur worden vervangen!
- In de bijlage vindt u:
  - de vertalingen van de gebruikte onderdelentekeningen
  - een overzicht van toesteltypen en de landen waarvoor deze onderdelenlijst bedoeld is.

### Önemli Bilgiler

- Yedek parçalar sadece yetkili tesisatçılar tarafından monte edilebilir!
- Aşağıdaki bilgileri ekli olarak bulabilirsiniz:
  - Tüm kullanılan parça tanımlarının tercümelemleri
  - Bu yedek parça listesinin geçerli olduğu tüm cihaz çeşitleri ve ülkelerin özeti.

Ersatzteilliste  
Spare parts list



6720905948.aa.RS-Verkleidung GB122


Verkleidung  
Housing

**GB122**  
**DE, AT, CH**

**1**



**Ersatzteilliste**  
**Spare parts list**



6720905949.aa.RS-Rahmen/Abgaseinheit/AusdehnungsgefäßGB122


Abgaseinheit  
Condensate drainage

**GB122**  
**DE, AT, CH**

**2**



**Ersatzteilliste**  
**Spare parts list**



6720905950.aa.RS-Gebläse/Gasarmatur GB122

Gebläse/Gasarmatur  
 fan/Gas valve


**GB122**  
**DE, AT, CH**

**3**





Ersatzteilliste  
Spare parts list



6720905951.aa.RS-Wärmetauscher/Brenner GB122

Wärmetauscher/Brenner  
heat exchanger/burner

**GB122**  
DE, AT, CH


**4**

Pos	Bezeichnung description	Bestell-Nr. Ordering no.									Bemerkungen Remarks
			GB122-11 (G20)	GB122-11(G25)	GB122-19 (G20)	GB122-19 (G25)	GB122-24 (G20)	GB122-24 (G25)	GB122-24K (G20)	GB122-24K (G25)	
1	Verbindungsstück m Rückschlagklappe V2	7099391	■	■	■	■	■	■	■		
2	Rückschlagventil m Dichtung V2	7099389	■	■	■	■	■	■	■		
3	Dichtung D83x60x1 5 Stück V2	7099985	■	■	■	■	■	■	■		
4	Dichtung Brenner GB122/GB132T	7099689	■	■	■	■	■	■	■		
5	Brenner GB122/GB132T-19/24kW	7099678			■	■	■	■	■		
5	Brenner GB122/GB132T-11kW	7099680	■	■							
6	Haltewinkel für Ionisationselektrode/	7099738	■	■	■	■	■	■	■		
7	Dichtung Glühzünder-Ionisationselektrode	7099684	■	■	■	■	■	■	■		
8	Glühzünder kompl.inkl. Adapter	7099006	■	■	■	■	■	■	■		
9	Schirm für Glühzünder	7100229	■	■	■	■	■	■	■		
10	Adapter Anschlusskabel Glühzünder	7099484	■	■	■	■	■	■	■		
11	Kabeldurchführung f. Glühzünder	7099217	■	■	■	■	■	■	■		
12	Ionisationselektrode	7100239	■	■	■	■	■	■	■		
13	Silikon Kitt f Isolierung GB122/GB132T	7099824	■	■	■	■	■	■	■		
14	Wärmetauscher-Rückschale GB122/GB132T	7099636	■	■	■	■	■	■	■		
15	Isolierung-Wärmetauscher-Rückschale für	7099670	■	■	■	■	■	■	■		
16	Klemmbügel 4 Stück für GB122/GB132T	7099734	■	■	■	■	■	■	■		
17	Lippendichtung DN36,4x24,4x6,3 (2x)	7099794	■	■	■	■	■	■	■		
18	O-Ring 26,3x5,33 (10x)	7099718	■	■	■	■	■	■	■		
19	Dichtung Vorderwand-Wärmetauscher	8 718 600 021	■	■	■	■	■	■	■		
20	Universal Spezialfett Silikon Tube 25gr	7099812	■	■	■	■	■	■	■		
21	Wärmetauscher Spiralrippenrohr GB122 V2	7099645	■	■	■	■	■	■	■		
22	Wärmetauscher-Vorderschale GB122/GB132T	7099634	■	■	■	■	■	■	■		
23	Isolierung-Wärmetauscher-Vorderschale	7099668	■	■	■	■	■	■	■		
24	Schaulochfenster Vorderschale GB122/	7099706	■	■	■	■	■	■	■		
25	Umlenkopf	7099646	■	■	■	■	■	■	■		
26	Isolierung Umlenkopf	7099658	■	■	■	■	■	■	■		
27	Halteklammer mit Schrauben M4x60	7099311	■	■	■	■	■	■	■		
28	Arretierung Spiralrippenrohr-	7099676	■	■	■	■	■	■	■		

**GB122**  
**DE, AT, CH**

Wärmetauscher/Brenner  
heat exchanger/burner

**Ersatzteilliste**  
**Spare parts list**



6720905952.aa.RS-Vorlauf/Rücklauf GB122


Vor/Rücklauf  
Flow/Return unit

**GB122**  
**DE, AT, CH**

**5**

Pos	Bezeichnung description	Bestell-Nr. Ordering no.	GB 122-11 (G20)	GB 122-11(G25)	GB 122-19 (G20)	GB 122-19 (G25)	GB 122-24 (G20)	GB 122-24 (G25)	GB 122-24K (G20)	GB 122-24K (G25)								Bemerkungen Remarks
1	Pumpe RSL 15-5 - 1P 130mm	7099788	■	■	■	■	■	■										FD<05/2001
1	Pumpe Wilo-3Stufen ohne Anschluß für	7099826	■	■	■	■	■	■										FD>05/2001
1	Pumpe Wilo-1stufig ohne Anschluß für	7099828							■	■								
2	Dichtung 1" Gummi (5x)	7099176	■	■	■	■	■	■	■	■								
3	Rohr-Rücklauf-Pumpe Wärmetauscher	7099638	■	■	■	■	■	■	■	■								
4	O-Ring 18,72 x2,62 (10x)	7099168	■	■	■	■	■	■	■	■								
5	Halteklemmen 5 St.-D=15/5 St-D=18mm	7099436	■	■	■	■	■	■	■	■								
6	Anschlussstück Rücklauf	7099786	■	■	■	■	■	■	■	■								
7	O-Ring 26,3x5,33 (10x)	7099718	■	■	■	■	■	■	■	■								
8	Lippendichtung DN36,4x24,4x6,3 (2x)	7099794	■	■	■	■	■	■	■	■								
9	Arretierung Spiralrippenrohr-	7099676	■	■	■	■	■	■	■	■								
10	Fühler-NTC kompl.mit O-Ring	7100136	■	■	■	■	■	■	■	■								
11	Anschlussstück Vorlauf m automat Entlüft	7099830	■	■	■	■	■	■	■	■								
12	Entlüfter automatisch 10bar	7099180	■	■	■	■	■	■	■	■								
13	Handentlüfter	7099672	■	■	■	■	■	■	■	■								
14	Rohr-Vorlauf-Wärmetauscher	7099640	■	■	■	■	■	■	■	■								
15	Halteclip 18mm	7099708	■	■	■	■	■	■	■	■								
<b>GB122</b> <b>DE, AT, CH</b>											Vor/Rücklauf Flow/Return unit							<b>5</b>

**Ersatzteilliste**  
**Spare parts list**



6720905953.aa.RS-Brauchwasserwärmetauscher GB122


Wärmetauscher  
heat exchanger

**GB122**  
**DE, AT, CH**

**6**



**Ersatzteilliste**  
**Spare parts list**



6720905955.aa.RS-3-Wege-Ventil Single GB122


**7**  
3-Wege-Ventil Single  
3-way valve Single  
**A**

**GB122**  
DE, AT, CH





**Ersatzteilliste**  
**Spare parts list**




6720905954.aa.RS-3-Wege-Ventil Kombi GB122

**7**  
3-Wege-Ventil Kombi  
3-way valve Kombi  
**B**

**GB122**  
**DE, AT, CH**

Pos	Bezeichnung description	Bestell-Nr. Ordering no.	GB122-24K (G20)	GB122-24K (G25)											Bemerkungen Remarks							
1	Sicherheitsventil 3bar Steckanschluß	7100888	■	■																		
2	Rohr-Anschluss-Siphon-Sicherheitsventil	7099626	■	■																		
3	Dichtungssatz-Siphon-Sicherheitsventil	7099628	■	■																		
4	Überströmventil 250mb kpl	7099160	■	■																		
5	O-Ring 14,48x2,62 (10x)	7099167	■	■																		
6	Stahlfeder 220.005A 5 St. 220.002A 1 St.	7100866	■	■																		
7	Halteclip für Überströmventil	7099132	■	■																		
8	Rücklauf T-Stück	7099125	■	■																		
9	O-Ring 18,72 x2,62 (10x)	7099168	■	■																		
10	Flachdichtung 3/4" (10x)	7100196	■	■																		
11	Federstecker D18,5 (5x)	7099352	■	■																		
12	Rücklauf-Verbindung Pumpe-Dreiwegeventil	7099766	■	■																		
13	Flachdichtung 1/2" (10x)	7100192	■	■																		
14	Dichtung 1" Gummi (5x)	7099176	■	■																		
15	Schraubverchluß m O-Ring M5x16	7099792	■	■																		
16	Dreiwegeventil kompl.mit Adapterkabel	7098250	■	■																		
17	Dreiwegeventil ohne Antrieb	7098972	■	■																		
18	Antrieb für Dreiwegeventil	7098970	■	■																		
19	Ventileinsatz	7098973	■	■																		
20	Mutter,Schneidring (3x)	7098968	■	■																		
21	Rohr-Rücklaufverbindung U122/124/GB132T	7099158	■	■																		
22	Federstecker Set a 5 Stück 200.002A	7099170	■	■																		
23	Halteclip für Rohrverbindung (4x)	7099156	■	■																		
24	Schutzkappe 3Wegeventil	7099790	■	■																		
<b>GB122</b> <b>DE, AT, CH</b>												3-Wege-Ventil Kombi 3-way valve Kombi							<b>7B</b>			

Ersatzteilliste  
Spare parts list



6720905957.aa.RS-Vorlauf Single GB122

**8**  
Vorlauf Single  
flow single  
**A**

**GB122**  
DE, AT, CH


Pos	Bezeichnung description	Bestell-Nr. Ordering no.	GB122-11 (G20)	GB122-11(G25)	GB122-19 (G20)	GB122-19 (G25)	GB122-24 (G20)	GB122-24 (G25)													Bemerkungen Remarks
1	Halteklappen 5 St.-D=15/5 St-D=18mm	7099436	■	■	■	■	■	■													
2	Rohr-Verbindung-Vorlauf-Rücklauf	7099179	■	■	■	■	■	■													
3	Rohr-Verbindung-Kesselvorlauf-Brenner	7099178	■	■	■	■	■	■													
4	O-Ring 18,72 x2,62 (10x)	7099168	■	■	■	■	■	■													
5	Flachdichtung 3/4" (10x)	7100196	■	■	■	■	■	■													
6	O-Ring 14,48x2,62 (10x)	7099167	■	■	■	■	■	■													
7	Federstecker Set a 5 Stück 200.002A	7099170	■	■	■	■	■	■													
8	Vorlauf/Rücklauf Warmwasser Fühler	7099187	■	■	■	■	■	■													
9	Rückschlagventil 1/4"	7098240	■	■	■	■	■	■													
10	Rohr-Vorlauf-Boiler	7099171	■	■	■	■	■	■													
11	Flachdichtung 1/2" (10x)	7100192	■	■	■	■	■	■													
12	Kessel-Füll-und Entleerungshahn kompl.	7100622	■	■	■	■	■	■													
13	Federstecker D18,5 (5x)	7099352	■	■	■	■	■	■													

GB122  
DE, AT, CH

Vorlauf Single  
flow single

**8A**

Ersatzteilliste  
Spare parts list



6720905956.aa.RS-Vorlauf Kombi GB122


**8**  
**B**

Vorlauf Kombi  
flow kombi

**GB122**  
**DE, AT, CH**



**Ersatzteilliste**  
**Spare parts list**



6720905958.aa.RS-Brennersteuerung/Kabelbaum GB122

Brennersteuerung/Kabelbaum  
 burner control/Cable tree

**GB122**  
**DE, AT, CH**

**9**



Pos	Bezeichnung description	Bestell-Nr. Ordering no.	GB122-11 (G20)	GB122-11(G25)	GB122-19 (G20)	GB122-19 (G25)	GB122-24 (G20)	GB122-24 (G25)	GB122-24K (G20)	GB122-24K (G25)							Bemerkungen Remarks
1	Gehäuse für UBA	7099104	■	■	■	■	■	■	■	■							
2	Thermomanometer	7099105	■	■	■	■	■	■	■	■							
3	Netzanschluss	7099107	■	■	■	■	■	■	■	■							
4	Anschlußkabel	7099108	■	■	■	■	■	■	■	■							
5	Anschlußplatine Handterminal	7099106	■	■	■	■	■	■	■	■							
6	UBA 1.5 ZETHOS	7 746 700 076	■	■	■	■	■	■	■	■							
7	Schalter	7100384	■	■	■	■	■	■	■	■							
8	Brennerautomat-Unterteil für UBA 1.5	7100379	■	■	■	■	■	■	■	■							
9	Kabelbaum GB122	7099632	■	■	■	■	■	■	■	■							
	Adapter Brauchwasserfühler	67903206	■	■	■	■	■	■	■	■							
	Abdeckkappe für Handterminal 5Stück	7099380	■	■	■	■	■	■	■	■							
	Kim GB122-11 Nr124 V2	7099800	■	■													Einbau nur durch ST
	Kim GB122-19 Nr123 V2	7099802			■	■											Einbau nur durch ST
	Kim GB122-24 Nr122 V2	7099804						■	■								Einbau nur durch ST
	Kim GB122-24K Nr121 V2	7099806								■	■						Einbau nur durch ST

<b>GB122</b> DE, AT, CH	Brennersteuerung/Kabelbaum burner control/Cable tree	9
----------------------------	---	---

**Übersetzungsliste**  
**List of translations**

Pos	Description
<b>1 Element of construction</b>	
1	Casing U122/124/GB122 without valve
2	Hex bolt M5x10 (5x)
3	Centering for Casing
4	Flap
5	Snap lock for Casing (10x)
	Paint pen RAL9016, 18ml (commercial)
<b>2 Element of construction</b>	
1	Cover vacuum chamber U112/U122/ GB122
2	Gasket , piece a 5m
3	Viewing hole window
4	Cover Frame upper part
5	Cable entry kit a 4 Piece
6	Holder
7	Gasket kit gas hydraulics
8	Holder
9	Boiler flue outlet
10	Lip gasket DN125
11	Lip gasket DN80
12	plugs kit
13	Gasket Flue pipe D60
14	Spring boiler connection piece
15	Pipe condensation header
16	Lip gasket D60 for condensation header
17	Condensation header
18	Gasket condensate header flue gas line
19	Gasket safety sensor
20	Sensor Flue gas with Gasket
21	siphon
22	Lock with Gasket
23	Gasket set syphon safety valve
24	Pipe connection syphon safety valve
25	Expansion vessel 12 litres
26	Flat gasket 1/2" (10x)
27	Pipe connection expansion vessel
<b>3 Element of construction</b>	
1	Fan GB122 V2
2	Cork gasket
3	Gasket D83x60x1 5 piece V2
4	Connection cable Fan
5	Venturi 19-24kW
6	Bolt kit gas control valve
7	Gasket gas control valve Venturi
8	Spring locking device
9	Gas valve
10	Gasket set gas control valve / gas
11	Rectifier
12	Pipe connection gas control valve gas
13	Flat gasket 1" (5x)
14	Inlet pipe
15	Gasket inlet pipe
16	Gas orifice EG G20 D5,55
	Bit set for Torx screwdriver
	LPG conversion kit for GB 122 for
	conversion kit LPG 3B/P GB122
<b>4 Element of construction</b>	
1	connecting piece rebound flap V2

**Übersetzungsliste**  
**List of translations**

Pos	Description
2	non-return valve sealing V2
3	Gasket D83x60x1 5 piece V2
4	Gasket Burner GB122/GB132T
5	Burner GB122/GB132T-19/24kW
6	Angle bracket for ionisation electrode/
7	Gasket heat ignition ionisation
8	Igniter incl. adapter
9	Screen for igniter
10	Adapter Connecting cable igniter
11	Cable entry for igniter
12	Ionisation electrode
13	Silicone kit f insulation GB122/GB132T
14	Heat exchanger rear liner GB122/GB132T
15	Insulation heat exchanger back liner
16	Clamp 4 Piece for GB122/GB132T
17	Lip gasket DN36,4x24,4x6,3 (2x)
18	O-ring 26,3x5,33 (10x)
19	Seal Heat Exchanger
20	Silicone special, tube 25gr
21	Heat exchanger spiral finned pipe
22	Heat exchanger front liner GB122/GB132T
23	Insulation heat exchanger front liner
24	Viewing hole window front cover GB122/
25	Diverting hood
26	Insulation pivoting hood
27	Retaining bracket with screws M4x60
28	Locking device spiral finned tube heat
<b>5</b>	<b>Element of construction</b>
1	Pump RSL 15-5 - 1P 130mm
2	Gasket 1" rubber (5x)
3	Pipe return pump Heat exchanger
4	O-ring 18.72 x2.62 (10x)
5	Support terminal 5 St.-D=15/5 St-D=18mm
6	Connector Return
7	O-ring 26,3x5,33 (10x)
8	Lip gasket DN36,4x24,4x6,3 (2x)
9	Locking device spiral finned tube heat
10	NTC sensor with O-ring
11	Connector flow m automatic device
12	Air vent automatic 10 bar
13	Manual air vent
14	Pipe flow heat exchanger
15	Support clip 18mm
<b>6</b>	<b>Element of construction</b>
1	Heat exchanger BW U122/124/GB122
2	Insulation Bw lower section m. snap-on
3	Pipe sanitary connection WW
4	Flat gasket 1/2" (10x)
5	Support terminal 5 St.-D=15/5 St-D=18mm
6	Pipe connection piece BW/WW
7	O-ring 14,48x2,62 (10x)
8	Flow/return Domestic hot water Sensor
9	O-ring 9,25x1,78 (10x)
10	Support clip for pipe connection (4x)
11	Spring Plug kit a 5 Piece 200.002A
12	Flow limiter U122/124/GB122
13	Pipe Sanitary connection U122/124/GB122

**Übersetzungsliste**  
**List of translations**

Pos	Description
14	Pipe connection piece BW/WW
15	Hot water standby sensor
16	Vent retrofit kit U122/124/GB122
17	Screw connection Air vent valve
18	O-ring 18.72 x2.62 (10x)
19	O-ring 17,12x2,62 kit a 10 Piece
<b>7A</b>	<b>Element of construction</b>
1	Safety valve 3 bar plug and socket
2	Pipe connection syphon safety valve
3	Gasket set syphon safety valve
4	Overflow valve 250mb
5	O-ring 14,48x2,62 (10x)
6	Steel spring 220.005A 5 pc. 220.002A 1
7	Support clip for Overflow valve
8	Return Tee
9	O-ring 18.72 x2.62 (10x)
10	Flat gasket 3/4" (10x)
11	Spring Plug D18,5 (5x)
12	Return connection pump 3-way valve
13	Flat gasket 1/2" (10x)
14	Gasket 1" rubber (5x)
15	Screw cap m O-ring M5x16
16	Three-way valve with adapter cable
17	Three-way valve without drive
18	Drive for Three-way valve
19	Valve element Diverting [changeover]
20	Nut, cutting ring (3x)
21	Pipe return boiler
22	Protective cap Three-way valve
<b>7B</b>	<b>Element of construction</b>
1	Safety valve 3 bar plug and socket
2	Pipe connection syphon safety valve
3	Gasket set syphon safety valve
4	Overflow valve 250mb
5	O-ring 14,48x2,62 (10x)
6	Steel spring 220.005A 5 pc. 220.002A 1
7	Support clip for Overflow valve
8	Return Tee
9	O-ring 18.72 x2.62 (10x)
10	Flat gasket 3/4" (10x)
11	Spring Plug D18,5 (5x)
12	Return connection pump 3-way valve
13	Flat gasket 1/2" (10x)
14	Gasket 1" rubber (5x)
15	Screw cap m O-ring M5x16
16	Three-way valve with adapter cable
17	Three-way valve without drive
18	Drive for Three-way valve
19	Valve element Diverting [changeover]
20	Nut, cutting ring (3x)
21	Pipe return connection U122/124/GB132T
22	Spring Plug kit a 5 Piece 200.002A
23	Support clip for pipe connection (4x)
24	Protective cap Three-way valve
<b>8A</b>	<b>Element of construction</b>
1	Support terminal 5 St.-D=15/5 St-D=18mm
2	Pipe connection flow return

**Übersetzungsliste**  
**List of translations**

Pos	Description
3	Pipe connection boiler flow burner
4	O-ring 18.72 x2.62 (10x)
5	Flat gasket 3/4" (10x)
6	O-ring 14,48x2,62 (10x)
7	Spring Plug kit a 5 Piece 200.002A
8	Flow/return Domestic hot water Sensor
9	Non-return valve 1/4"
10	Pipe flow boiler
11	Flat gasket 1/2" (10x)
12	Boiler fill and Drain valve with O-ring
13	Spring Plug D18,5 (5x)
<b>8B</b>	<b>Element of construction</b>
1	Support terminal 5 St.-D=15/5 St-D=18mm
2	Pipe connection flow return
3	Pipe connection boiler flow burner
4	O-ring 18.72 x2.62 (10x)
5	Flat gasket 3/4" (10x)
6	O-ring 14,48x2,62 (10x)
7	Spring Plug kit a 5 Piece 200.002A
8	Flow/return Domestic hot water Sensor
9	Non-return valve 1/4"
10	Pipe connection flow BW
11	Support clip for pipe connection (4x)
12	Boiler fill and Drain valve with O-ring
13	Spring Plug D18,5 (5x)
<b>9</b>	<b>Element of construction</b>
1	Housing for UBC
2	Thermo-pressure gauge
3	Network connection
4	Connecting cable
5	Connecting board hand terminal
6	UBA 1.5 VR software 3.8
7	Switch
8	Burner automatic device lower section
9	Cable harness GB122
	Adapter process water filler
	Protective hood for hand terminal 5 pc.
	Kim GB122-11 Nr124 V2
	Kim GB122-19 Nr123 V2
	Kim GB122-24 Nr122 V2
	Kim GB122-24K Nr121 V2

**Gerätetypen**  
**Types of appliances**

Gerät Appliance	Bestell-Nr. Ordering no.	Land Country	Bemerkungen Remarks
<b>GB122-11(G25)</b>	7105032	Deutschland	
<b>GB122-19 (G25)</b>	7105042	Deutschland	
<b>GB122-24 (G25)</b>	7105052	Deutschland	
<b>GB122-24K (G25)</b>	7105062	Deutschland	
<b>GB122-11 (G20)</b>	7105030	Deutschland,Schweiz,Österreich	
<b>GB122-19 (G20)</b>	7105040	Deutschland,Schweiz,Österreich	
<b>GB122-24 (G20)</b>	7105050	Deutschland,Schweiz,Österreich	
<b>GB122-24K (G20)</b>	7105060	Deutschland,Schweiz,Österreich	



Bosch Thermotechnik GmbH  
Sophienstraße 30-32  
D-35576 Wetzlar  
[www.buderus.de](http://www.buderus.de)

**Buderus**